



Your RemoteCam™ Camera End gets mounted into the RCM-LCM™ as shown in the two images below. Simply snap the RemoteCam™ Camera End into the stainless steel clip in the RCM-LCM™ with your cables oriented as shown.

The RCM-LCM™ then gets screwed into a standard double gang wall plate using the four supplied oval head screws. One thumb screw is provided for mounting your camera to the mount.

FRONT VIEW



TOP VIEW

