


## RCM™ Spring Clip Camera Mount Installation Guide

Thank you for purchasing our recently revised **RCM™ Spring Clip Camera Mount** featuring a spring clip for easier installation!

- The spring clip is attached to the back plate using the provided black  $8-32 \times 1/4$ " phillips pan head machine screw.
- Attach the camera shelf to the two studs at the bottom of the wall plate using the [2] cap nuts and lock washers.
- Secure the wall plate to a standard double gang electrical box using the [4] black 6-23  $\times$  3/4" phillips oval head screws.



Please Note: If using a low voltage trim ring, please hold the camera module securely with two hands when inserting it into the spring clip to prevent it from dropping into the wall!





RemoteCam™ Camera End module mounted in the spring clip.

Model #:	Sup	port	ing:

RCM-CP6™ Cisco Precision 60 Camera

RCM-EE4™ Polycom EagleEye IV

RCM-L10™ LifeSize 10X & Camera S

RCM-PH1™ Tandberg/Cisco PHD 12x, 4xS1 & 4xS2 (Precision 40)

RCM-SD2<sup>™</sup> Sony EVI-H100V

RCM-SD3™ Sony EVI-HD3 & EVI-HD7
RCM-SR1™ Sony SRG-120H, SRG-300H & SRG-360HE

Panasonic AW-HE40, AW-HE60 & AW-UE70

Lumens VC-A20P, VC-A50P/N/S, VC-A51A, VC-A60S & VC-A70H

Marshall CV620, CV612 & PTZ Optics PT Series