



BEFORE YOU GET STARTED

Please make sure that you have all parts indicated before you begin mount assembly, and that materials are mounted in accordance with commercial construction best practices.



INCLUDED KIT-SPECIFIC PART LIST

1. Wall Mount Plate (Qty 1)
2. Module Cradle (Qty 1)
3. Mounting Channel (Qty 1)
4. Camera Plate (Qty 1)
5. 8-32 Hex Nuts (Qty 2)
6. 8-32 x 7/16 Pan Head Screws (Qty 2)
7. 1/4-20 x 3/8 Thumb Screw (Qty 1)
8. 6-32 x 5/16 Torx Screws (Qty 2)

PARTS NOT INCLUDED

9. Wall Mount Screws (Qty 4)
(Integrator-supplied based on type of wall and site requirements)
10. Cisco Precision 60 Camera (Qty 1)

ASSEMBLY INSTRUCTIONS

1. Mount the Wall Mount Plate (No. 1, Qty 1) utilizing four of the perimeter holes and Wall Mount Screws (No. 9, Qty 4).
2. The rectangular hole *must* line-up with the rectangular hole in the back of the Module Cradle (No. 2, Qty 1).

3. Ensure that your CAT5e/CAT6 cable is pulled through the rectangular hole in both the Mounting Channel (No. 3, Qty 1) and the Module Cradle (No. 2).
4. Knock out holes on the Mounting Channel (No. 3) to line-up with the Wall Mount Plate (No. 1). The Mounting Channel holes line up with every 5th hole (meaning there will be 3 unpunched holes between each punched hole).
5. The Mounting Channel (No. 3) can be separated along the horizontal laser perforation to shorten if desired.
6. Attach the Module Cradle (No. 2) to the Mounting Channel (No. 3) using the 8-32 Hex Nuts (No. 5, Qty 2).
7. Attach the Mounting Channel (No. 3) to the Wall Mount Plate (No. 1) utilizing the 8-32 x 7/16 Pan Head Screws (No. 6, Qty 2).
8. Attach the Camera Plate (No. 4, Qty 1) to the Cisco Precision 60 Camera (No. 10) utilizing the 1/4-20 x 3/8 Thumb Screw (No. 7, Qty 1).
9. Attach the Camera Plate (No. 4) and the Cisco Precision 60 Camera (No. 10) to Module Cradle (No. 2), securing with the 6-32 x 5/16 Torx Screws (No. 8, Qty 2).